

























# INSTALLATION MANUAL





CR-045A12  
CR-045A14

*RoHS*  ISO9001:2008





|                                                                                        |                                                                                        |                                                                                        |                                                                                          |                                                                                          |                                                                                          |
|----------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------|
|  X1 |  X1 |  X1 |  X1  |  X2 |  X1 |
| GLASS                                                                                  | GLASS                                                                                  | KQ-03                                                                                  | BB-03                                                                                    | 8B-2-15                                                                                  | 8B-5                                                                                     |
|  X1 |  X1 |  X1 |  X2  |  X1 |  X1 |
| PJ-4566                                                                                | PJ-4565                                                                                | PJ-4152                                                                                | LZ-5012                                                                                  | PJ-4028                                                                                  | PJ-4038                                                                                  |
|  X2 |  X2 |  X1 |  X1  |  X1 |  X1 |
| PJ-4133                                                                                | PJ-4412                                                                                | LS-1105                                                                                | PJ-4578                                                                                  | LT-01                                                                                    | PJ-4131                                                                                  |
|  X5 |  X1 |  X8 |  X13 |                                                                                          |                                                                                          |
| PJ-4577                                                                                | 8S-180                                                                                 | PJ-4606                                                                                |                                                                                          |                                                                                          |                                                                                          |


Install the wall aluminum profile



As the photo show mark the size then install the stainless steel fixed part .



Insert the glass profile to the wall aluminum profile .




**Attention:** Do not remove the Black corner protector until insert well the glass into the wall profiles and fit well to prevent glass broken and splitted.





3

As the drawing show install and fix the sliding track on the fixed glass .





4

1. Install the groove and fix in the glass side .
2. Make the glass gel on the waterproof strip then fixed .




5

Install the plastic decoration part .




6

1. Install the wheel on the glass .
2. Install the bottom waterproof
3. Hang the glass on the sliding track ,make sure the glass on the groove.
4. Install the fix part .




7

1. Install the waterproof.
2. Install the U shape waterproof Gasket.



8

1. Install the profile cap .
2. Install the top decoration part .



Make the glass gel then make sure without shower in 24hours .

